


### Installing Batteries

- Slide the cover off the battery compartment
- Place the two AA alkaline batteries into the battery compartment
- Slide cover back into place being careful not to catch any wires

### Connecting Sender Unit (refer diagram below)

- The recommended installation point of the sender is 200mm after the pump
  - If you have no room after the pump, the sender can be fitted before the pump, however you need to ensure that there are no tiny pin holes, as this will allow air to enter the hose line and the water may drain back into the tank
  - If this happens it will make a machine gun noise as it is sucking in the air
  - If your receiver unit is on you may get irregular water flow as there will be no water in the sender unit but as your vehicle is moving the sender will turn thinking that water is propelling through which may show consumption that hasn't actually occurred
  - If the sender is fitted on the pressure side any leaks become obvious



- The thread specifications of the sender unit are 1/2" BSP male
- Make sure the sender is fitted with the water flow in the direction of the arrow
- The display comes pre-wired with an approximately 1.4m cable
- Extra 1.4m & 3m extension leads are available for the three pin plugs
- Up to 6 leads may be joined to make 9.8m in total length
- You will need to purchase two 1/2" BSP female connectors to the size hose you have, usually 1/2" or 3/4" and two clamps. "John Guest quick connections" also have fittings to suit their hose and the 1/2" BSP sender unit
- **Please Note:** Sender leads cannot be cut and joined – this will void your warranty, extension leads must be used

### Programming Monitoring Capacity

- Press "DISPLAY" button to turn display on
- Next press the "PROG" button - "PROG" will blink on the LCD display
- Press and release "RESET" button to choose the value of the right digit
- Once the value has been chosen press "PROG" button to save the value - it will then go to the next digit
- Repeat the above procedure to program the values for the five digits from right to left
- The first time the meter is used, fill the water tank and then use it normally until empty
- At this point note how many usable litres the tank holds and reset the meter accordingly
- If there is no input for one minute during the programming procedure, the programming procedure will be terminated and goes back to the original status
- **Please Note:** The maximum monitoring capacity is 99,999 litres

### **For Example:**

- If you have an 85 litre tank, set the display at 85 litres
- Use normally until empty
- If the display shows you have 10 litres left then you have a usable capacity of 75 litres
- It is normal for tanks to hold approx 10 - 12 % less than the stated tank size. This is because the tanks is drained from the sides, rounded corners, baffles, etc
- Enter the usable capacity amount - in this example it would be 75 litres

### **Operating**

- The Topargee H2F-SM Surface Mount will automatically turn on and display the litres remaining when there is water flowing through the sensor eg a tap is turned on
- It will automatically turn off 10 seconds after there is no water flowing
- To manually check remaining litres, press and release "DISPLAY" button and remaining litres will be displayed for 10 seconds

### **End of Capacity Alert**

- The Topargee H2F-SM Surface Mount will give an audible alert and the digits will blink on the LCD display when the remaining capacity reaches zero or minus

### **Resetting**

- When the water tank has been refilled press "DISPLAY" button to turn display on
- Next press the "RESET" button for six seconds
- The "RESET" on the LCD display blinks twice and gives an audible alert
- The unit will then be reset to the originally programmed value
- **Please Note:** You may find it easier to use the side of your fingernail or coin to hold the button in for the six seconds

### **Low Battery Power Alert**


- When the battery power is low, there will be an audible alert and the empty battery symbol on the right-hand corner of the LCD display blinks
- The alert status will be cancelled when the batteries are replaced by new batteries
- The data of the last status will be memorised and restored

### **To Change from Litres to Gallons or Gallons to Litres**

- Remove the 2 AA batteries
- Press and hold the "PROG" button while reinstalling the batteries
- Release the button when you hear the long beep
- The display will be switched (from litres to gallons or gallons to litres)
- Wait until the screen turns off and the unit will store the setting

### Fitting in Conjunction with Showermi\$ers

- If you are fitting a Topargee H2F-SM Surface Mount in conjunction with a Showermi\$er, the sender needs to be fitted between the water tank and the Showermi\$er return line
- For plumbing diagram refer to the Showermi\$er Installation Guide



**Please Note:** Due to continuous product improvement, specifications are subject to change without notice.

**Contact Us:** [sales@topargee.com.au](mailto:sales@topargee.com.au) / 0418 767 967